



Focal Plane Array Shutter Mechanism

of the JWST NIRSpec Detector System

Kathleen Hale
Rajeev Sharma
NASA's Goddard Space Flight Center



Outline



- Requirements
- Chamber location
- Shutter system design
- Motor specs
- Dry lubrication
- Control system
- Environmental cryogenic function testing
- Test results

- Acronyms
 - FPA- Focal Plane Assembly
 - SCA- Sensor Chip Assembly
 - JWST – James Webb Space Telescope
 - NIRSpec – Near Infrared Spectrum



Derived Requirements





- Light baffle mechanism for ground testing for NIRSPEC FPA
 - 1 degree of freedom operation
 - Operate in vacuum (10^{-6} Torr) – mechanism not required to hold vacuum
 - Open or close shutter in about one minute
 - Operate through several thousand cycles over life
 - Fit within “Experimental Shell” diameter $\varnothing 302$ mm ($\varnothing 11.9$ ”) envelope and on $\varnothing 279$ mm ($\varnothing 11.0$ ”) plate
 - Keep maximum height, at any time during operation, < 228.5 mm (9”)
-



Derived Requirements




- Light tightness
 - Required attenuation = $1 \text{ E}4$
 - Path length designed for specified gap distance
 - Door rotation $> 90^\circ$
 - Temperature
 - Operating: -253°C to 27°C (20K to 300K)
 - Operate in any direction 1g field
 - Hold position with power off in any direction 1g field
-






Shutter in Open Configuration



Shutter in Motion





Stepper Motor





- Requires 0.0107 kg m² (0.155 oz. in²) to move door
 - Includes inertia of door and light box
 - Requires 0.095 N m (0.84 in. lb) of detent torque (3.2x margin)
 - Stepper Motor Requirements
 - 2 phase
 - 186.7 gear ratio
 - 30 degrees/step
 - Right angle gear head
 - Dry lubrication
- 0.16° per step
resolution at output




Dry Plating Process for Stepper Motor




- Actuator bearings and gear train parts are lubed with Molybdenum Di-Sulfide
- 22 parts per motor
- We required 0.0001" thick coating
 - Thickness required was determined by maximum thickness allowed due to motor part tolerancing
- Contamination not an issue as motor is contained within a closed volume






Electrical System & Control




- National Instrument (NI) ESP 300 series stepper controller (3 amp/axis)
- Used resolver and both switches for feedback and control
- Constant current source to motor





Environmental Verification Test Set-up - Side View





Environmental Test Set-up

- Radial support bearing already dry lubricated by a cage that wears away and provides lubricant
 - Bearing mount made of AL-6061. Calculations performed to ensure CTE mismatch would not affect bearing performance
- Cryogenic compatible end-of-travel sensors purchased
 - Were designed by manufacturer for cryogenic environment but were not previously tested
 - Tested in house by slowly introducing into liquid Nitrogen





Lessons Learned – Cryogenic Testing



- Verify all solder connections so ensure connections will not separate when reach cryogenic temperatures
 - Check and re-check all electrical connections before buttoning up the chamber
 - Use Belleville washers to keep interfaces tight through thermal changes
 - Light tightness will be tested when integrated into project's cryogenic dewar with the detectors
-